Windtronic 2 Anemometer


Instrument is reasonably robust, but please handle it carefully, return it to its pouch and place in RO box after use.



• Switch on and off Push button I

Selectable Units

Push button M repeatedly, to cycle through KM/H (Kilometres/Hour), KTS (Knots), M/S (Meters/Second), MPH (Miles/Hour)



• LCD Display

The display shows the following readings:

Current wind speed (in selected units)

Maximum wind speed. (MX)

Average wind speed. (AV)

Beaufort number. (A bar graph showing current value is always displayed, regardless of wind speed units.